

ISEL Code List - Lista de Códigos

TV	
ABEX	0345
ACCESS HD	0222
ACER	0417, 0418
ACTION	0355
ADMIRAL	0009, 0147, 0150, 0349
AD	0353, 0356
ADVENT	0072, 0146, 0379, 0388
ADVENTURA	0428
AFFINITY	0270, 0166, 0046, 0170
AIKO	0361
AIWA	0358, 0114, 0355, 0460, 0618
AKAJI	0410, 0308, 0002, 0058, 0100, 0106, 0308, 0381, 0382, 0403, 0404
AKAWA	0355
AKIBA	0072, 0379
AKIO	0121, 0348, 0359, 0362, 0427
AKIRA	0372
AKISHI	0002
ALBATRON	0386
ALLEGRO	0009
ALUX	0615, 0621
A-MARK	0348, 0366
AMERICA ACTION	0355
AMPRO	0353
AMTRON	0355
ANAM	0092, 0096, 0345, 0355
ANHUA	0355
AOC	0019, 0205, 0075, 0076, 0140, 0203, 0204, 0206, 0217, 0425
AOMI	0284
APEX	0059
APEX DIGITAL	0058, 0059, 0064, 0193, 0196, 0287, 0288, 0374
ARIO	0193
ARION	0218
ASCENT	0141
ASTAR	0190, 0391
ASUS	0461
ATEC-PANDA	0411
ATVIO	0030, 0021, 0182, 0135, 0022, 0038, 0186, 0231, 0238, 0243, 0244, 0282, 0289, 0274, 0373, 0400, 0614, 0616, 0618, 0621, 0627, 0632, 0634, 0636, 0401, 0280, 0059, 0121, 0137, 0209, 0278, 0279, 0283, 0315, 0319, 0355, 0361, 0372, 0423, 0428, 0446
AUMARK	0348
AURIA	0075, 0076
AURUS	0268, 0276
AVENTURA	0360
AVERA	0193
AVOL	0103
BATMAN	0397
BAYSONIC	0355
BELL & HOWELL	0114, 0456
BENQ	0160
BERKSHIRE	0109
BLU SENS	0139, 0229, 0258, 0108, 0176, 0201, 0257
BLUE LIGHT	0347, 0108, 0176, 0201
BLUE POINT	0348, 0355
BLUE SKY	0355
BRADFORD	0355
BRIILLIAN	0413
BROKSONIC	0121, 0147, 0148, 0307, 0308, 0355, 0356, 0366, 0433, 0456
CARVER	0072, 0074
CCE	0072
CELEBRITY	0004
CELERA	0058, 0068
CENTURY	0355, 0362
CETRONIC	0355
CHAMPION	0114
CHANGHONG	0058, 0068
CHIO	0056
CINERAL	0121, 0361
CITIZEN	0123, 0147, 0308, 0348, 0361, 0362, 0456
CLARION	0355
CLASSIC	0355
COBIA	0225, 0104, 0273, 0373
COBY	0138, 0168, 0191, 0192, 0197, 0207, 0305, 0321, 0324, 0329, 0391, 0421, 0422, 0442, 0443, 0444, 0628
COLOMBIA	0072
COMMERCIAL SOLUTIONS	0108, 0109
CONTEC	0355
CONTEXT	0250, 0251
CONTINENTAL	0627, 0633
CORNEA	0452
CORTEX	0250
CRAIG	0265, 0355
CROSLEY	0017, 0004, 0072, 0074, 0120
CROWN	0355
CTX	0366
CURTIS	0046, 0047, 0102, 0166, 0169, 0187, 0193, 0195, 0227, 0231, 0251, 0389, 0396, 0445, 0450
CURTIS MATHES	0227, 0057, 0002, 0009, 0020, 0072, 0074, 0100, 0109, 0114, 0121, 0150, 0152, 0278, 0279, 0348, 0349, 0350, 0440, 0456
CXC	0355
CYBERHOME	0393
CYTRON	0396
DAEWOO	0017, 0119, 0185, 0118, 0013, 0069, 0114, 0120, 0121, 0122, 0123, 0184, 0248, 0254, 0263, 0278, 0279, 0361, 0373, 0377, 0384, 0404, 0407, 0615
DAYTEK	0180, 0059, 0381, 0388
DELL	0078, 0415, 0416
DELUX	0372
DENON	0020
DIGIMATE	0214
DIGITAL LIFESTYLES	0303
DIGITREX	0182, 0104, 0097, 0616
DIRECTV	0420
DISNEY	0148, 0360
DIVS	0217
DUMONT	0353
DURABRAND	0140, 0147, 0355, 0359, 0360, 0388
DURAMATIC	0147
DW DISPLAY	0017, 0117
DWIN	0009
DYNASTY	0355, 0362, 0366
DYNEX	0210, 0011, 0148, 0121
EBEN	0271
EKT	0244, 0185, 0226, 0255, 0022, 0135, 0158, 0188, 0217, 0223, 0229, 0233, 0243
ELECTROBAND	0004
ELECTROGRAPH	0235, 0284
ELECTROHOME	0145, 0147, 0308, 0388
ELECTRON	0195, 0227
ELEKTRA	0121, 0140, 0278, 0348, 0353, 0355, 0362, 0363, 0377, 0384, 0387, 0394, 0456
ELEMENT	0013, 0239, 0023, 0130, 0215, 0238, 0240, 0241, 0615, 0621, 0635
ELITE	0024
EMERSON	0215, 0071, 0096, 0114, 0115, 0116, 0121, 0122, 0123, 0130, 0140, 0147, 0216, 0239, 0278, 0279, 0336, 0355, 0359, 0360, 0362, 0364, 0370, 0372, 0373, 0376, 0377, 0392, 0428, 0433, 0438, 0439
EMPREX	0300, 0303
ENVISION	0019, 0075, 0076, 0204, 0206
EPSON	0289
EPWORTH	0114
EOD	0075, 0076
EOD AURIA	0075, 0076
EOD/VEOD AURIA	0075, 0076
ESA	0002, 0359, 0360, 0438
EVIANT	0234
E-VISION	0332
FANCO	0038, 0243
FAVI	0102
FISHER	0114
FLUID	0013, 0239
FUJITSU	0281
FUNAI	0004, 0115, 0215, 0216, 0355, 0359, 0360, 0427, 0428, 0438
FUTURETECH	0355
G VISION	0242, 0622
GATEWAY	0235, 0313
GE	0002, 0009, 0010, 0058, 0108, 0109, 0121, 0140, 0279, 0279, 0345, 0349, 0350, 0353, 0364
GENERAL ELECTRIC	0010, 0058, 0108, 0114, 0, 0279
GFM	0137, 0215, 0216, 0360
GHIH	0269, 0021, 0620, 0623
GIBALTER	0353
GO VIDEO	0002, 0348, 0382
GOLDSTAR	0140, 0334, 0335, 0363, 0366
GOLDTEXT	0078
GOTEX	0078, 0080
GPX	0448
GRADIANTE	0090
GRUNPY	0355
H & B	0285
HAIER	0021, 0102, 0033, 0039, 0042, 0098, 0103, 0134, 0388
HALLMARK	0140
HANNS G	0317
HANNSPREE	0220, 0221, 0317
HANTEK	0355
HARLEY DAVIDSON	0427
HARMANKARDON	0072, 0074
HARWARD	0032, 0074
HARVEMY	0009, 0150
HDTV	0115, 0148, 0215
HELIOS	0285
HELLO KITTY	0121, 0279
HEWLETT PACKARD	0203, 0419, 0458
HIDEAR	0224
HIMITSU	0355, 0364, 0378
HISENSE	0129, 0012, 0144, 0029, 0033, 0102, 0130, 0320, 0375, 0389, 0617
HITACHI	0020, 0024, 0048, 0049, 0050, 0051, 0052, 0102, 0114, 0152, 0372, 0427, 0456, 0618
HITEKER	0103
HKPRO	0244, 0169, 0185, 0460, 0618
HP	0203, 0419
HUMAX	0420
HYUNDAI	0208, 0328
I BEROSTAR	0264
ILO	0359, 0398, 0115, 0148, 0296, 0304, 0310, 0360, 0399
INCO	0250
INFINITY	0072, 0074
INFOCUS	0108, 0285, 0332
INITIAL	0304, 0399
INSIGNIA	0011, 0210, 0003, 0028, 0029, 0033, 0147, 0148, 0209, 0209, 0111, 0212, 0291, 0294, 0304, 0360, 0381, 0382, 0396, 0438
INTEO	0353
INTERVISION	0202
IRIS	0323
ISMPHONY	0102, 0103, 0262
JBL	0072, 0074
JC PENNEY	0068, 0140, 0145, 0348, 0349
JCB	0004
JCM	0242, 0323
JEC	0072
JENSEN	0072, 0146, 0325, 0379, 0396
JINXING	0070
JVC	0038, 0016, 0087, 0090, 0095, 0086, 0088, 0089, 0091, 0095, 0147, 0148, 0242, 0244, 0308, 0338, 0345, 0388, 0460, 0618, 0622, 0624, 0625, 0636
JWIN	0002
K VISION	00219
KC	0453
KDS	0447, 0630, 0631
KEC	0355
KENWOOD	0004
KLH	0058, 0383
KODAK	0105, 0244, 0262, 0383
KOLIN	0142
KONKA	0376, 0381, 0382, 0383, 0382
KTV	0355, 0362
KURAZAI	0456
LANIX	0136
LASONIC	0283
LEGEND	0133, 0193
LEXUS	0249, 0200, 0372
LG	0124, 0003, 0125, 0131, 0126, 0132, 0135, 0140, 0143, 0364, 0353, 0354, 0363, 0366, 0457
LG ALPS	0131
LLOYD'S	0427
LOGDENT	0456
LOGDINGSTAR	0326
LOEWE	0072, 0073, 0387
LOGIK	0456
LXI	0009, 0068, 0072, 0074, 0109, 0114, 0140, 0353
MAG	0023, 0167
MAGNASONIC	0123, 0428
MAGNAVOX	0007, 0026, 0070, 0071, 0072, 0073, 0376, 0438
MAJESTIC	0083, 0206, 0235, 0280
MAKANA	0169, 0614
MARANTZ	0072, 0073, 0074, 0145, 0171, 0412
MASTER	0373
MATSUI	0072
MATSUNOSHITA	0052, 0095, 0096
MAXENT	0171, 0235, 0236, 0337
MB QUART	0137
MEGAPOWER	0366
MEGATRON	0020, 0140, 0366
MEMOREX	0134, 0011, 0023, 0096, 0106, 0114, 0140, 0145, 0147, 0148, 0215, 0307, 0308, 0348, 0360, 0388, 0429, 0456, 0590
MERRITT	0362
MGA	0140, 0145
MIDLAND	0109, 0345, 0353
MIKADO	0002, 0348
MINTEK	0304, 0399
MISAKAI	0360
MITACHI	0355
MITSUBISHI	0009, 0092, 0140, 0145, 0150, 0318, 0339, 0414
MITSUBISHI ELECTRIC	0140, 0414
MITSUI	0022, 0135, 0186, 0201, 0058, 0179, 0229, 0230, 0344, 0355, 0370, 0372, 0376, 0377, 0384, 0392, 0395, 0396, 0402
MITZU	0082
MIYAKI	0355
MONIVISION	0366
MONTGOMERY WARD	0009, 0145
MOTOROLA	0009, 0150
MOVER A MEXICO	0266, 0228, 0271, 0102, 0243
MTC	0342, 0343, 0348, 0355
MULTITECH	0135
NAD	0067, 0068, 0140, 0152
NAOKI	0372, 0373, 0381, 0392
NAXA	0098, 0102, 0187, 0194, 0258, 0265, 0450
NEC	0042, 0145, 0318, 0412
NETTV	0235
NEW ACOUSTIC DIMENSION	0067, 0068, 0140
NEWTECH	0114
NEXUS	0012, 0130, 0209
NEXUS ELECTRONICS	0130
NIKEI	0355, 0372
NIKKO	0068, 0114, 0140, 0363
NORCENT	0019, 0164, 0203, 0206, 0292, 0374, 0375, 0425
NORWOOD MICRO	0296
NTC	0361
NUVISION	0196, 0295, 0411
OCOSMO	0043
OLEVIA	0142, 0163, 0290
ONKING	0355
ONN	0228, 0623
ONWA	0447, 0630, 0631
OPTIMUS	0092, 0095, 0096, 0114, 0152, 0428, 0429, 0459
OPTIQUE	0329
OPTOMA	0221
OPTONICA	0009, 0150
ORION	0089, 0147, 0148, 0307, 0348, 0349, 0343, 0343
PACIFIC	0355
PACKARD BELL	0348, 0355, 0362, 0456
PANABLACK	0096
PANASONIC	0014, 0036, 0094, 0092, 0095, 0009, 0068, 0093, 0096, 0114, 0140, 0345, 0348, 0377, 0429, 0430, 0431, 0432, 0459, 0460
PANATRONIC	0147
PARK	0194
PENNEY	0068, 0109, 0140, 0435, 0348, 0350
PHILCO	0009, 0020, 0072, 0074, 0078, 0115, 0145, 0147, 0355, 0360, 0362, 0368, 0370, 0372, 0376, 0438
PHILIPS	0026, 0007, 0073, 0072, 0071, 0074, 0077, 0078, 0079, 0081, 0083, 0084, 0115, 0156, 0157, 0206, 0330, 0353, 0360, 0369, 0427, 0436, 0437, 0438, 0439, 0460, 0618, 0079
PHILIPS MAGNAVOX	0024, 0102, 0274, 0031, 0036, 0152, 0153, 0229, 0460, 0618, 0626
PLANAR	0109, 0152
POLAROID	0040, 0229, 0256, 0135, 0023, 0055, 0058, 0064, 0102, 0167, 0169, 0178, 0228, 0273, 0285, 0293, 0296, 0315, 0316, 0381, 0389, 0396, 0422, 0424, 0426, 0612, 0614, 0628, 0308, 0348, 0360, 0388, 0429, 0456, 0590
PORTLAND	0121, 0278, 0279, 0361
PREVIEW	0023, 0167
PRIMA	0011, 0133, 0134, 0146, 0379
PRINCETON	0366
PRISM	0072, 0345
PROSCAN	0035, 0043, 0046, 0047, 0102, 0108, 0109, 0130, 0166, 0169, 0231, 0238, 0239, 0241, 0242, 0250, 0251, 0254, 0269, 0322, 0345, 0349, 0350, 0450
PROTON	0140, 0141, 0346
PROTRON	0214
PROVIEW	0023, 0167
PULSAR	0353
PYLE	0061, 0246
PYLE HOME	0246
QUANTUMFX	0043, 0261
QUASAR	0102, 0043, 0092, 0095, 0096, 0097, 0104, 0341, 0345, 0429, 0459, 0616, 0618
RADIO SHACK	0004, 0109, 0114, 0140, 0355, 0427
RCA	0035, 0267, 0056, 0101, 0002, 0009, 0027, 0046, 0047, 0053, 0102, 0107, 0108, 0109, 0110, 0111, 0121, 0130, 0137, 0145, 0150, 0152, 0159, 0166, 0169, 0227, 0231, 0241, 0242, 0243, 0244, 0250, 0251, 0256, 0269, 0278, 0308, 0326, 0345, 0349, 0350, 0351, 0352, 0357, 0378, 0381, 0382, 0440, 0449, 0450, 0454, 0619, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683, 0684, 0685, 0686, 0687, 0688, 0689, 0690, 0691, 0692, 0693, 0694, 0695, 0696, 0697, 0698, 0699, 0700, 0701, 0702, 0703, 0704, 0705, 0706, 0707, 0708, 0709, 0710, 0711, 0712, 0713, 0714, 0715, 0716, 0717, 0718, 0719, 0720, 0721, 0722, 0723, 0724, 0725, 0726, 0727, 0728, 0729, 0730, 0731, 0732, 0733, 0734, 0735, 0736, 0737, 0738, 0739, 0740, 0741, 0742, 0743, 0744, 0745, 0746, 074

.....	3158, 3174, 3185, 3194
.....	3201, 3219, 3243
DANTAX	3242
DAYTEK	3053, 3063, 3078, 3086
.....	3101, 3102, 3105, 3112
.....	3113, 3114, 3115, 3142
.....	3144, 3158, 3174, 3185
.....	3194, 3201, 3219
DENON	3116, 3005, 3234, 3340
DESAY	3234
DIGITALMAX	3311
DIGIX	3111
DIGIX MEDIA	3106, 3176
DIRECTED VIDEO	3196
DISNEY	3154, 3170, 3172
DIOTECH	3195
DTX	3088
DURABRAND	3199, 3256
DVD	3031, 3063, 3068, 3098
.....	3105, 3135, 3154, 3161
.....	3184, 3199, 3208, 3209
.....	3246, 3258, 3263, 3275
.....	3278, 3282
DVD2000	3138
DYNEX	3270
EKT	3062, 3082, 3183
ELEKTRA	3100, 3112, 3169, 3189
.....	3235
EMERSON	3003, 3132, 3144, 3170
.....	3172, 3202, 3206
ENTERPRISE	3003
EVL	3231
FISHER	3150, 3163
FOROX	3186
FUNAI	3172
FUSSION	3192, 3244
GATEWAY	3297, 3300
GE	3117, 3196
GENERAL ELECTRIC	3117, 3196
GFM	3172
GO VIDEO	3003, 3024, 3118, 3119
.....	3120, 3133, 3164, 3196
.....	3201, 3300, 3006
GOLDEN VISION	3279
GOLDSTAR	3003, 3133
GOTECH	3108, 3042
GPX	3059, 3121, 3210
GRADIENTE	3210
GREEN HILL	3196
GREENHILL	3196
GRUNDIG	3045, 3112
HAIER	3248
HARMANKARDON	3167, 3292, 3293, 3303
.....	3336, 3337
HARMONY	3216
HELLO KITTY	3169
HITACHI	3024, 3035, 3172, 3173
HITEKER	3067
HUMAX	3314
HYUNDAI	3064
ILO	3311
ILUV	3339
INITIAL	3196
INSIGNIA	3010, 3021, 3003, 3106
.....	3172, 3270
INTEGRA	3116, 3139, 3146, 3147
.....	3317, 3321
IRRADIO	3220
IRT	3120
JBL	3053, 3167, 3292
JVC	3124, 3125, 3204, 3205
.....	3003, 3126, 3301, 3325
.....	3335
JWIN	3067, 3177, 3283
KAWASAKI	3199
KENWOOD	3005, 3101, 3128, 3129
.....	3204
KLH	3160, 3196, 3199, 3200
.....	3257
KONKA	3130, 3182
KOSS	3210
LAFAYETTE	3148
LASONIC	3091, 3131, 3132
LEXICON	3271
LG	3003, 3014, 3133, 3273
LINTRON	3310
LITEON	3294, 3300, 3310, 3311
.....	3316
LM VIEW	3096
LOEWE	3291
LOGITECH	3330
LOFSOHN	3078
MAGNAVOX	3019, 3040, 3045, 3128
.....	3134, 3136, 3172, 3173

.....	3220, 3223, 3227, 3252
MAJESTIC	3067, 3076, 3077, 3104
.....	3105
MAKENA	3095
MARANTZ	3019, 3034, 3045, 3136
.....	3303, 3326
MATRIX	3179
MATSUI	3067
MCINTOSH	3015, 3305
MEMOREX	3011, 3023, 3276, 3022
.....	3169, 3170, 3277
MICROSOFT	3117, 3264, 3342
MINTEK	3196
MIRAGE	3085
MITSUBISHI	3138, 3139, 3204
MITSUI	3058, 3059, 3077, 3105
.....	3141, 3144, 3166, 3178
.....	3202, 3224, 3251, 3285
MITZU	3214, 3215
MTB	3084
MUSTEK	3071
NAD	3003, 3329
NAOKI	3066, 3081, 3099, 3202
.....	3249, 3250
NAXA	3059
NEC	3204
NECSTAR	3100
NESA	3196
NEW ACOUSTIC DIMENSION	3003
NORCENT	3107, 3142, 3144, 3176
OLEVIA	3022
ONKYO	3147, 3284, 3146, 3019
.....	3128, 3137, 3154, 3197
.....	3223, 3225, 3269, 3314
.....	3317
TRAVEL SOUND	3083
TREDEX	3084
TRENT	3103
TRUTECH	3172
UNIREX	3094
UNITRON	3210
OPPO	3271, 3272, 3274
ORITRON	3209, 3210
OZAKI	3054
PANASONIC	3005, 3016, 3127, 3132
.....	3019, 3226, 3318, 3319
.....	3345
PARK	3250
PHILCO	3042, 3080, 3092, 3148
.....	3149, 3154, 3162, 3165
.....	3171, 3172, 3181, 3200
.....	3244, 3245, 3247, 3261
PHILIPS	3033, 3006, 3017, 3135
.....	3019, 3034, 3040, 3045
.....	3048, 3128, 3134, 3136
.....	3172, 3220, 3227, 3268
.....	3300, 3303, 3304, 3309
PHILIPS KARAOKE	3135
PIONEER	3198, 3139, 3180, 3005
.....	3140, 3204, 3268, 3287
POLAROID	3160, 3162, 3298, 3307
POLK AUDIO	3034, 3045, 3303
PRESIDIAN	3172, 3311
PROCEED	3067
PRO-IMAGE	3148
PROSCAN	3117
PYLE	3253
QWESTAR	3186, 3210
RCA	3009, 3020, 3117, 3046
.....	3030, 3042, 3079, 3139
.....	3170, 3193, 3196, 3199
SHARP	3200, 3262, 3288, 3314
.....	3317, 3333, 3334, 3343
RE-BL	3025
RIO	3133
ROTEL	3124
ROYAL	3057, 3076, 3148, 3212
.....	3236, 3237
SAMPO	3073
SAMSUNG	3002, 3013, 3038, 3024
.....	3005, 3031, 3043, 3047
.....	3118, 3119, 3122, 3123
DVD	3031
EMERSON	3206
JVC	3125, 3204, 3205
LG	3003, 3133
PHILCO	3154, 3162
RCA	3020, 3117
SAMSUNG	3031, 3043, 3119
SANYO	3029
SONY	3032, 3039
TOSHIBA	3019, 3041
.....	3338
SHERWOOD NEWCASTLE	3297
SHINSONIC	3015, 3051, 3117

DVD RECORDER

SILO	3106
SMC	3033, 3133
PANASONIC	3005
PHILIPS	3040
SAMSUNG	3122
SAT/CABLE	
ACCESS COMMUNICATIONS	6013, 6090
ADAMS CABLE TV	6013
ADB	6039, 6041, 6048, 6085
.....	6091, 6116
ALLEGIANCE COMMUNICATIONS	6013
AMINO	6039, 6041, 6084, 6085
.....	6086, 6087, 6088, 6091
.....	6117
ARION	6014
ARMSTRONG	6013, 6029
ARRIS	6013, 6046, 6041, 6047
.....	6090, 6112, 6114
ARVIG COMMUNICATION SYSTEMS	6013, 6041
ARVIG COMMUNICATION	6013, 6041, 6114
ASSOCIATION	6048
GCI	6029
GOI	6029
GE	6062
GENERAL COMMUNICATIONS	6013, 6029
GENERAL INSTRUMENT	6013, 6020, 6032, 6047
GIGACABLE	6008, 6016, 6043, 6045
GOI	6022, 6067
GOOGLE	6097
GOPELL	6006
GRANDE COMMUNICATIONS	6013, 6029
GREAT PLAINS COMMUNICATIONS	6013
HAWAIIAN TELCOM	6039
HTS	6022, 6067
HUAWAI	6114
HUGHES	6059
HUGHES NETWORK SYSTEMS	6003, 6059
HUMAX	6003
HUNIAJ	6003
I-LINK	6104
INSIGHT	6013, 6029
INTER MOUNTAIN CABLE	6007, 6029, 6030
IZZI TV	6013, 6007, 6123
JERROLD	6013, 6020, 6032, 6034
.....	6047
JVC	6022, 6067, 6121
KAON	6043, 6055
KNOLOGY	6013, 6029, 6031
KOOLCONNECT	6085
LG	6003, 6098
LIBERTY CABLEVISION	6013
LUMOS NETWORKS	6039, 6041
MAGNAVOX	6065
MASSILLON CABLE	6013, 6090
MARANA TELEPHONE ASSOCIATION	6048, 6085, 6087
MAXCOM	6009
MEDIACOM	6013, 6029, 6114
MEDIASTREAM	6013
MEGACABLE	6005, 6013, 6019
MEGACABLE HD	6013
MEMOREX	6065
METROCAST CABLEVISION	6013, 6029, 6114
MI-CONNECTION	6029
MIDCONTINENT	6013, 6114
MIDCONTINENT COMMUNICATIONS	6013, 6029
MID-HUDSON CABLE	6013
MINERVA NETWORKS	6057
MITSUBISHI	6059
MOTOROLA	6041, 6033, 6013, 6018
.....	6032, 6047, 6050, 6052
.....	6112, 6113, 6114
MOVIEBEAM	6044
MOXI	6090, 6112
MTA	6048, 6085, 6087
MTS	6041, 6052, 6113
NAGRAVISION	6053
NETWORKTECHNOLOGIES	6096
NEVOTEK	6122
NEVHAWK COMMUNICATIONS	6013, 6050
NEXT LEVEL	6047
NORTHLAND COMMUNICATIONS	6013
NU TELECOM	6039, 6041
OMEGASAT	6101
OPENBOX	6105
OPTIMUM	6029
OPTUS	6032
PACE	6003, 6011, 6013, 6029
.....	6041, 6050, 6114

.....	6049, 6061, 6062, 6065
.....	6069, 6070, 6071, 6072
.....	6074, 6098
DIRECTV HUGHES	6059
DIRECTV PHILIPS	6060
DISH	6002, 6010, 6017, 6022
.....	6024, 6067, 6121
DISH NETWORK	6010, 6017, 6067, 6099
.....	6121
DISH NETWORK 1	6010
DISH NETWORK SYSTEM	6022, 6024
DISHPRO	6010, 6022, 6024, 6067
EAGLE COMMUNICATIONS	6013, 6090
EASTLINK	6013, 6090
ECHOSTAR	6010, 6017, 6022, 6024
.....	6067, 6099, 6121
ENSEO	6081
ENTONE	6056, 6084, 6086, 6091
.....	6094, 6115
EVOLUTION	6007, 6055
EXPRESSVU	6022
FIDELITY COMMUNICATIONS	6013
FRONTER COMMUNICATIONS	6013, 6041, 6067
GOI	6029
GOI	6029
GE	6062
GENERAL COMMUNICATIONS	6013, 6029
GENERAL INSTRUMENT	6013, 6020, 6032, 6047
GIGACABLE	6008, 6016, 6043, 6045
GOI	6022, 6067
GOOGLE	6097
GOPELL	6006
GRANDE COMMUNICATIONS	6013, 6029
GREAT PLAINS COMMUNICATIONS	6013
HAWAIIAN TELCOM	6039
HTS	6022, 6067
HUAWAI	6114
HUGHES	6059
HUGHES NETWORK SYSTEMS	6003, 6059
HUMAX	6003
HUNIAJ	6003
I-LINK	6104
INSIGHT	6013, 6029
INTER MOUNTAIN CABLE	6007, 6029, 6030
IZZI TV	6013, 6007, 6123
JERROLD	6013, 6020, 6032, 6034
.....	6047
JVC	6022, 6067, 6121
KAON	6043, 6055
KNOLOGY	6013, 6029, 6031
KOOLCONNECT	6085
LG	6003, 6098
LIBERTY CABLEVISION	6013
LUMOS NETWORKS	6039, 6041
MAGNAVOX	6065
MASSILLON CABLE	6013, 6090
MARANA TELEPHONE ASSOCIATION	6048, 6085, 6087
MAXCOM	6009
MEDIACOM	6013, 6029, 6114
MEDIASTREAM	6013
MEGACABLE	6005, 6013, 6019
MEGACABLE HD	6013
MEMOREX	6065
METROCAST CABLEVISION	6013, 6029, 6114
MI-CONNECTION	6029
MIDCONTINENT	6013, 6114
MIDCONTINENT COMMUNICATIONS	6013, 6029
MID-HUDSON CABLE	6013
MINERVA NETWORKS	6057
MITSUBISHI	6059
MOTOROLA	6041, 6033, 6013, 6018
.....	6032, 6047, 6050, 6052
.....	6112, 6113, 6114
MOVIEBEAM	6044
MOXI	6090, 6112
MTA	6048, 6085, 6087
MTS	6041, 6052, 6113
NAGRAVISION	6053
NETWORKTECHNOLOGIES	6096
NEVOTEK	6122
NEVHAWK COMMUNICATIONS	6013, 6050
NEXT LEVEL	6047
NORTHLAND COMMUNICATIONS	6013
NU TELECOM	6039, 6041
OMEGASAT	6101
OPENBOX	6105
OPTIMUM	6029
OPTUS	6032
PACE	6003, 6011, 6013, 6029
.....	6041, 6050, 6114

PANASONIC	6068, 6069, 6114
PAUL BUNYAN COMMUNICATIONS	6048
PAYSAT	6065
PHILIPS	6060, 6025, 6013, 6036
.....	6059, 6065
PICO DIGITAL	6120
PIONEER	6029, 6031
PIONEER TELEPHONE	6048, 6086, 6091
PRIME	6054
PROSCAN	6061, 6062
QWEST	6003
RADIOSHACK	6047
RCA	6049, 6061, 6062, 6063
RCN	6013, 6029
REACH BROADBAND	6013, 6029, 6114
ROGERS	6013, 6029, 6030, 6031
SAMSUNG	6003, 6029, 6071, 6072
.....	6073, 6110, 6114
SASKTEL	6035, 6041
SATELLITE CAN	6078
SATHAWK	6105
SBA	6257
SCHURZ COMMUNICATIONS	6013, 6029, 6114
SCIENTIFIC ATLANTA	6013, 6029, 6031
.....	6039, 6040, 6050, 6114
SERVICE ELECTRIC	6013, 6029, 6090, 6114
SHAW	6013, 6029, 6090, 6112
.....	6114
SHAW DIRECT	6047, 6067
SHENTEL	6013, 6029, 6090, 6114
SKITTER TV	6058
SKY	6011
SKY HD	6018
SKY HD PACE	6018
SKY MOTOROLA	6018
SKY PACE	6003, 6011, 6018
SKY PHILIPS	6018, 6025
SKY RCA	6025
SKY TECHNICOLOR	6018
SKY THOMSON	6018, 6025
SKY UEC	6028
SKY VETV	6018
SKY ZENITH	6018
SKY+HD	6027
SKY+HD PACE	6003
SKYVIEW	6026
SOLOMEND	6105
SONICVIEW	6102, 6103
SONY	6037, 6094

SOUNDBAR

BEAST	7018
DENON	7011
EVL	7014
HARMANKARDON	7010
JBL	7010
JVC	7108
LG	7003, 7189, 7190
MISIK	7017, 7016
PHILIPS	7005
RCA	7015
SAMSUNG	7002
SELECT	7019
SONY	7004, 7090
TOSHIBA	7009
VIZIO	7008
YAMAHA	7006, 7007
ZVOX	7013

STREAMING

A.C.RYAN	6590, 6594, 6595
ABS	6507
ACCESS HD	6560
AIRLINK 101	6574
AIRTV	6612
ALIENWARE	6507
ALPHA DIGITAL	6560
AMLLOGIC	6549
AMTC	6560
APEX DIGITAL	6568
APPLE	6518, 6577, 6603, 6604
APPLE TV	6598
ARMADA	6549
ARRIS	6590
ARTEC	6573
ASUS	6522
AT&T/A&T UVERSE	6589
BEE LINK	6610
BOXEE	6601
BRITE-VIEW	6552
BUFFALO	6588
CENTRONICS	6565
CETON	6507
CHANNEL MASTER	6506, 6516, 6524, 6565, 6584
CIBERPOWER	6507
CISCO	6589
CLARO VIDEO	6504
COBY	6578
CONSOLIDATED COMMUNICATIONS	6524
COSHIP	6502, 6505
CYBERPOWER	6507
DAEWOO	6563
DELL	6507
DIAMOND	6595
DIGITAL STREAM	6561
DIGI WAVE	6565
DISH NETWORK	6567
D-LINK	6508, 6513, 6537, 6556, 6601
DUNE	6613
DVICO	6531, 6559
ECHOSTAR	6567, 6612
EDAL	6608
ENSEO	6575
ENTONE	6524
EPSON	6557
EVOLUTION	6535
FIREBIRD SYSTEMS	6565
FRONTLINE	6609
FUNAI	6529
GATEWAY	6507
G-BOX MIDNIGHT	6548
GE	6565
GENERAL INSTRUMENT	6590
GENIATECH	6504, 6591
GHIA	6549, 6553
GOODMIND	6565
GRIDLINK	6564
HEWLETT PACKARD	6507
HOMEWORX	6539, 6543, 6544, 6550
HOWARD COMPUTERS	6507
HP	6507
HUSH	6507
IBUYPOWER	6507
INET ACCESS	6560
INSIGNIA	6555
IOMEGA	6515, 6582, 6596
IVIEW	6521
JERROLD	6590

KERALA VISION	6503
KM8	6608
KOLLINS	6591
LASONIC	6564
LG	6530, 6555
LINKSYS	6507
LOMEGA	6515
MAGIC TV	6611
MAGNAVOX	6529, 6557
MATRICOM	6548, 6549
MEDIA CENTER PC	6507
MEDIABOX	6611
MEDIA SONIC	6539, 6543, 6544, 6550
MEMOREX	6569
MI	6586, 6606
MICCA	6532, 6540
MICROGEM	6572
MICROSOFT	6507, 6511, 6512, 6542
MILLET	6606
MIND	6507
MINIX	6541, 6547
MOTOROLA	6589, 6590
MYGICA	6591, 6609
NETGEAR	6509, 6510, 6525, 6527, 6545, 6546
NEXT LEVEL	6590
NIVUSMEDIA	6507
NORTHGATE	6507
NVIDIA	6551
OMNIVERSE	6587, 6607
ORTEK	6523
PACE	6589
PANASONIC	6538, 6593
PATRIOT	6526
PCT	6506
PHILCO	6557
PIVOS	6504, 6591
PIXEL MAGIC	6611
POPCORN HOUR	6514
QNAE	6583
RADIO SHACK	6590
RCA	6528, 6554, 6562, 6566
RICAVISION	6507
ROKU	6501, 6597, 6599, 6600, 6605
RTC	6565
SAMSUNG	6558, 6576
SANSONIC	6564
SCIENTIFIC ATLANTA	6589
SEAGATE	6519
SHAW DIRECT	6590
SLING MEDIA	6517, 6602, 6612
SONY	6507, 6520
STACK 9	6507
STAR CHOICE	6590
SUNKEY	6579
SYLVANIA	6557
SYSTEMAX	6507
TAGAR SYSTEMS	6507
TCL ROKU	6501
TIBO	6591
TIVAX	6560
TOSHIBA	6507
TOUCH	6507
TVIX	6531
UEBO	6595
U-VERSE	6589
VENSIMILE	6549
VENTURER	6566
VIEWSONIC	6507, 6533, 6534
VIZIO	6536, 6592
VOODOO	6507
WAVE BROADBAND	6535
WESTERN DIGITAL	6515
WINEGARD	6566, 6570, 6585
WOW!	6535
XBOX	6511, 6512, 6542
XIAOMI	6586, 6606
XTREAMER	6581
ZAPPITI	6614, 6615
ZENITH	6555
ZENTECH	6574
ZINWELL	6571
ZT GROUP	6507

VCR

ADMIRAL	5033
ADVENTURA	5035
AIKO	5008
AIWA	5035
AKAI	5043

AMERICA ACTION	5008
AMERICAN HIGH	5018
AUDIOVOX	5008
BELL & HOWELL	5032
BROKSONIC	5006, 5008
CANON	5018
CARVER	5026
CCE	5008, 5025
CINERAL	5008
CITIZEN	5008
COLT	5025
CRAIG	5009, 5025
CROSLEY	5026
CURTIS MATHES	5018, 5019, 5021, 5023, 5028
DAEWOO	5008, 5009, 5036, 5037, 5011
DENON	5011
DYNATECH	5035
ELEKTRA	5015, 5025, 5035
EMEREX	5002, 5005
EMERSON	5006, 5008, 5016, 5017, 5035
FISHER	5009, 5032, 5033
FUJI	5018
FUNAI	5035
GARRARD	5035
GE	5018, 5028, 5029, 5033
GENERAL ELECTRIC	5018, 5028, 5029
GOLDSTAR	5010, 5035, 5041
GRADIENTE	5035
GRIS	5007
HARLEY DAVIDSON	5035
HARMANKARDON	5026
HARWOOD	5025
HI-Q	5009
HITACHI	5011, 5013, 5014, 5035, 5042
HUGHES NETWORK SYSTEMS	5011
INSTANT REPLAY	5018
JC PENNEY	5011, 5018
JVC	5012, 5013, 5014, 5015, 5016
KEC	5008
KENWOOD	5013, 5014
KLH	5025
KODAK	5018
LG	5010, 5041
LLOYD'S	5035
LOGIK	5025
MAGNASONIC	5008
MAGNAVOX	5018, 5026, 5035
MARANTZ	5018, 5026
MATSUSHITA	5018, 5019, 5021, 5023
MEI	5018
MEMOREX	5009, 5018, 5019, 5021, 5023, 5032, 5033, 5035
MGA	5016
MINOLTA	5011
mitsubishi	5013, 5014, 5016, 5033, 5035
MOTOROLA	5018, 5033
MTC	5035
MULTITECH	5025, 5035
NAP	5018
NEC	5013, 5014, 5032
OLYMPUS	5018
OPTIMUS	5019, 5021, 5023, 5032, 5033
ORION	5006, 5008, 5017
PANASONIC	5018, 5019, 5020, 5021, 5022, 5023, 5024, 5025, 5026, 5028
PENNEY	5018
PENTAX	5011
PHILCO	5013, 5014, 5018, 5025
PHILIPS	5018, 5026, 5027, 5028
PIONEER	5013, 5014
POLK AUDIO	5026
PROSCAN	5028, 5029
PROTECH	5025
QUASAR	5018, 5019, 5021, 5023
RADIO SHACK	5035
RCA	5011, 5018, 5028, 5029, 5033, 5035, 5037
RCN	5028
REALISTIC	5009, 5018, 5032, 5033, 5035
SAMSUNG	5030, 5036, 5037, 5039
SANKY	5040
SANSUI	5013, 5014, 5035

SANYO	5009, 5031, 5032, 5033
SCOTT	5006, 5016, 5036, 5037
SEARS	5009, 5011, 5018, 5032, 5035
SEMP	5035
SHARP	5033, 5034, 5035, 5038
SHINTOM	5025
SIGNATURE	5018
SIGNATURE2000	5018
SINGER	5025
SONY	5002, 5003, 5004, 5005, 5018, 5035
STS	5011
SYLVANIA	5016, 5018, 5026, 5035
SYMPHONIC	5035, 5037
TEAC	5035
TECHNICS	5018, 5019, 5021, 5023, 5028, 5029
TEKNIKA	5018, 5035
THOMAS	5035
TOSHIBA	5016, 5036, 5037
VECTOR	5036
VECTOR RESEARCH	5037
VIDEO CONCEPTS	5036, 5037
VILLAIN	5035
WARDS	5009, 5011, 5018, 5025, 5026, 5028, 5033, 5035
WHITE WESTINGHOUSE	5025
XR-1000	5018, 5025, 5035
ZENITH	5035, 5037

DIGITAL CONVERTER

ACCESS HD	6414
AIRLINK 101	6430
ALPHA DIGITAL	6414
AMTC	6414
APEX DIGITAL	6401
ARTEC	6429
ATSC	6403, 6405, 6407, 6408, 6435
BLU-SENS	6409
CASTI	6406
CHANNEL MASTER	6423
COBY	6403, 6413, 6422, 6431
COSHIP	6426
DAEWOO	6419
DAYTEK	6406
DIGITAL STREAM	6402
DISH NETWORK	6424
DOSYU	6435
ECHOSTAR	6424
EONTECH	6435
GE	6421
GEBOX	6435
GMJ	6403
GOODMIND	6421
GRIDLINK	6420
HITV	6433
HOMEWORX	6437
IKONVERT	6401
INSIGNIA	6411
KOOLTEK	6417
KSPRO	6405
LASONIC	6420
LINK BITS	6422
MAGNAVOX	6412
MAKENA	6441
MASTER	6408, 6415, 6416
MEMOREX	6425
MICROGEM	6428
MITZU	6404
NUTEK	6404
PHILCO	6412
QUANTUM VIEW	6439
RCA	6418, 6438
SANSONIC	6420
SM	6410, 6422, 6436
STEREN	6415, 6440
SUNKEY ELECTRONIC	6432, 6434
SYLVANIA	6412
TIVAX	6414
ZENITH	6411
ZENTECH	6430
ZINWELL	6427

HOME THEATER

3D LAB	4030
AIWA	4008, 4018, 4025, 4054
ALBA	4030
ARISTONA	4030
ATVIO	4065
AUDIOVOX	4032

BLUE PARADE	4016
CLASSIC	4026
DAEWOO	4026, 4061
DANTAX	4030
DENON	4011
DIGIX	4049
DURABRAND	4066
ELEKTRA	4062
EMERSON	4034
GRUNDIG	4030
HT	4026
INTEGRA	4016
JVC	4042, 4030
KENWOOD	4010, 4020, 4027, 4035, 4036, 4046
LG	4003, 4013, 4021, 4037, 4046, 4047, 4048
LG RIO	4013
LOEWE	4030
LUFSOHN	4033
MAGNAVOX	4030
MAJESTIC	4039
MARANTZ	4030
METZ	4016
MICROMEDIA	4030
MICROMEGA	4030
NIRO	4060
ONKYO	4009, 4019, 4026, 4045
OPTIMUS	4016
PANASONIC	4005, 4015, 4022, 4028, 4038, 4068
PHILCO	4039, 4050, 4051, 4058, 4063, 4067
PHILIPS	4007, 4017, 4024, 4030, 4064, 4069
PIONEER	4006, 4016, 4023, 4029, 4040, 4070
POLK AUDIO	4030
PYE	4030
RCA	4016
SAMSUNG	4002, 4012, 4043, 4044
SCHNEIDER	4030
SHARP	4056, 4057
SKANTIC	4030
SONY	4004, 4014, 4031, 4055
TEAC	4016, 4053
TECHNICS	4052
THETA DIGITAL	4016
TOSHIBA	4059
YAMAHA	4030, 4041
ZENITH	4047